








 100:50  
 1  
 1.1.17

### Washprimer 1K CF

**Plus Reducers**

 **Fast**  
 **Medium**  
 **Slow**  
 **Extra Slow**

 1.2-1.5  
1.7-2.2 bar  
 1-2 coats  
 recoat after 15 min at 20°C, within 24 hrs at 20°C




 100:25:35  
 5  
 S2.02.02



### Colorbuild Plus

**Colorbuild Plus Hardener Non**

**Colorbuild Plus Activator Non Sanding**



 1.2-1.5  
1.7-2.2 bar  
 1 coat  
 recoat after 15 min at 20°C within 4 hrs at 20°C







 100:0-30  
 14  
 5.0.2

### Autowave

**Activator WB**

 1.2-1.5  
1.7-2.2 bar  
 Solid: 2 x 1 coat  
Metallic 2 x 1 + ½ coat  
 between coats: until matt before clearcoat 15 min at 25°C










 100:60:20  
 31  
 S1.05.01


### Autoclear LV Superior Fast




**Autoclear LV Superior Hardener**

**Autoclear LV Superior Reducers**

 **Fast**  
 **Medium**  
 **Slow**

 1.2-1.4  
1.7-2.2 bar  
 2 coats  
 between coats: 3-5 min at 20°C  
before curing: 3-5 min at 20°C  
 6 hrs at 20°C  
15 min 60°C







 100:60:20  
 31  
 S1.05.01

### Autoclear LV Superior Fast

**Autoclear LV Superior Hardener**

**Autoclear LV Superior Accelerator**

**Accelerator**

 1.2-1.4  
1.7-2.2 bar  
 2 coats  
 between coats: 3 min at 20°C  
before curing: 3 min at 20°C  
 3 hrs at 20°C  
12 min 60°C



M600  
M200

S4.01.00  
S4.03.01



**Use suitable respiratory protection**

Akzo Nobel Car Refinishes recommends the use of a fresh air supply respirator.